

The following table provides **Watts Loss** data for Fuji Electric's **FRENIC-Mini C2** series drives.

FRENIC-Mini C2					
Voltage	Hp	Drive Model Number	Drive Watts Loss		
			Low carrier frequency	High carrier frequency	At Stop
Three phase 230VAC	1/8	FRN0001C2S-2U	20	23	9
	1/4	FRN0002C2S-2U	27	32	9
	1/2	FRN0004C2S-2U	40	50	9
	1	FRN0006C2S-2U	60	77	9
	2	FRN0010C2S-2U	91	110	14
	3	FRN0012C2S-2U	128	165	14
	5	FRN0020C2S-2U	203	260	14
	7.5	FRN0025C2S-2U	240	300	19
	10	FRN0033C2S-2U	280	350	19
	15	FRN0047C2S-2U	440	520	19
	20	FRN0060C2S-2U	520	680	21
Three phase 460VAC	1/2	FRN0002C2S-4U	28	45	11
	1	FRN0004C2S-4U	41	64	11
	2	FRN0005C2S-4U	63	103	14
	3	FRN0007C2S-4U	89	149	14
	5	FRN0011C2S-4U	135	235	14
	7.5	FRN0013C2S-4U	170	300	19
	10	FRN0018C2S-4U	220	380	19
	15	FRN0024C2S-4U	300	480	19
	20	FRN0030C2S-4U	330	580	21
Single phase 230VAC	1/8	FRN0001C2S-7U	21	24	9
	1/4	FRN0002C2S-7U	29	34	9
	1/2	FRN0004C2S-7U	41	51	9
	1	FRN0006C2S-7U	64	80	9
	2	FRN0010C2S-7U	101	129	11
	3	FRN0012C2S-7U	143	180	11
Single phase 115VAC	1/8	FRN0001C2S-6U	21	24	9
	1/4	FRN0002C2S-6U	31	36	9
	1/2	FRN0003C2S-6U	53	63	9
	1	FRN0005C2S-6U	89	106	11

Note:

The carrier frequency is programmable, via parameter F26, see the FRENIC-Mini C2 instruction manual INR-SI47-1729(*)-E for additional information.